

# HB16 MOD 0 BLK/DST

## INSTRUCTION MANUAL



### ⚠ WARNING !!

- Adult supervision required.
- May be hazardous up to 50 meters.

- Stop shooting when the battery power is low.
- Do not adjust the motor without authorization or by certified technician.
- Always wear eye protection when using this product.
- Misuse or careless handling of this product may cause injury.

- This product is intended for users 18 years or older.
- Read all instructions before using this product.
- The buyer and the user of this product shall adhere to all local laws regulating the usage and the ownership of airsoft guns.

### RETRACTABLE GOS-V2 STOCK



Pull the release lever to adjust the position of the stock. (6 positions).




Pull the locking lever until it clicks into place to secure the position of the stock.


### MAINTENANCE



Press the magazine release button and slide your magazine out.



Return the hop up dial to normal position and insert the cleaning rod from the lead edge of the inner barrel.



Be sure to have the rod facing down and reaching to the end. Remove clogged pellets.

### TROUBLE SHOOTING



Adjust screw when the gear noise becomes shrilly.

Use a screwdriver to adjust the screw at the bottom of the grip.



No operation

Check the wire set contact on the motor.



No operation

Make sure the battery is fully charged.

### MOVABLE & OPTIONAL PARTS



Set to an appropriate position.



Fasten the knob.

### FRONT SIGHT ADJUSTMENT



Turn the knob counterclockwise.



Remove the front sight post.



G-03-130 (Optional)

You can install accessories onto the rail.


### REAR SIGHT ADJUSTMENT



Press down the button to fold the rear sight.



Remove the screw by turning counterclockwise.



Pull the charging handle to the rear and remove the rear sight off you G&G Armament gun.

### PARTS LIST

HB16 MOD0 - 01	Flash Suppressor	HB16 MOD0 - 17	Magazine
HB16 MOD0 - 02	Lower Handguard Set	HB16 MOD0 - 18	Lower Receiver Set
HB16 MOD0 - 03	Upper Handguard Set	HB16 MOD0 - 19	Trigger Guard Set
HB16 MOD0 - 04	Outer Barrel Set	HB16 MOD0 - 20	Selector Plate
HB16 MOD0 - 05	Hop Up Set	HB16 MOD0 - 21	Rear Frame Lock Pin Set
HB16 MOD0 - 06	Delta Ring	HB16 MOD0 - 22	Grip Set
HB16 MOD0 - 07	Inner Barrel	HB16 MOD0 - 23	Motor
HB16 MOD0 - 08	Upper Receiver Set	HB16 MOD0 - 24	Grip Bottom Set
HB16 MOD0 - 09	Heavy Bolt Set	HB16 MOD0 - 25	GOS-V2 Stock Set
HB16 MOD0 - 10	Port Cover Set	HB16 MOD0 - 26	Gear Box Set
HB16 MOD0 - 11	Front Frame Lock Pin Set	HB16 MOD0 - 27	Detachable Front Sight Set
HB16 MOD0 - 12	Bolt Catch Set	HB16 MOD0 - 28	Right Selector Cap
HB16 MOD0 - 13	Selector Lever Set	HB16 MOD0 - 29	Wire
HB16 MOD0 - 14	Magazine Catch Set	HB16 MOD0 - 30	Rear Sight
HB16 MOD0 - 15	Sling Swivel Mount	HB16 MOD0 - 31	Handguard Retainer
HB16 MOD0 - 16	Stock Tube	HB16 MOD0 - 32	Imitation Gas Tube

### TAIWAN

Sales Dept. | sales@guay2.com , b2b@guay2.com  
 Technology Support Dept. | support@guay2.com  
 PR Dept. | pr@guay2.com


Chang Hua Headquarter | Tel : +886-4-798-9000 Fax : +886-4-798-9900  
 No.999, Zhonghua Rd. Shengang Township, Changhua County 50955, Taiwan (R.O.C.)

Taipei | Tel : +886-2-2692-2000 Fax : +886-2-2692-4000  
 11F-3., No.27, Lane 169, Kangning St. Shijr City, Taipei County 22180, Taiwan (R.O.C.)

Dealer

▶ The grouped parts may all be purchased from the G&G Support Department.

▶ E-Mail: support@guay2com



G2-201409-01-英