

MAGAZINE SETTING

CAUTION

It is strongly recommended the use of G&G BB pellets only. Using low quality BB pellets will shorten product life span and void product warranty.



Open the cover of magazine.



Load G&G 5.95mm BB pellets into the magazine.



Close the cover plate then turn the gear until the sound changes.



Insert the magazine until you heard a click sound.

REAR SIGHT ADJUSTMENT

CAUTION

Keep the selector on Safe mode until you are actually ready to shoot.



SPECIAL SHOOTING
Used for precision firing.



COMMON SHOOTING
Used for full automatic firing.



WINDAGE KNOB (left / right adjustment)
ELEVATION KNOB (up / down adjustment)

MOVABLE PARTS




Detachable rear sight.



Detachable carrying handle.



Turn the knobs counterclockwise to disassemble.



Take off the carrying handle or rear sight to install other accessories.

MAINTENANCE

CAUTION


► Make sure no dirt gets into the chamber to avoid clogging of pellets.
► Hop-up may be unstable for 200 to 300 rounds after using silicone oil. This is the normal operation of the gun.
► Never use CRC-556, WD40, or other corrosive lubricants.



Remove the magazine.



Return the hop up dial to normal position and insert the cleaning rod from the lead edge of the inner barrel.



Be aware to have the rod facing down and reaching to the end, and remove clogged pellets.

RETRACTABLE STOCK



Press the stock release lever to unlock. Adjust the position (6 position).



Press the stock release lever to unlock. Adjust the position (6 position).



Press the stock release lever to unlock. Adjust the position (6 position).



► G-03-065-2
Forward Grip (ABS Injection)

TROUBLE SHOOTING

CAUTION


► Use only the G&G battery purchased from your local dealer.



The screw at bottom of the grip. Please use the screwdriver to adjust.



Check the wire set contact with motor.



Check the battery and connector.

PARTS LIST

For FF15-L / FF16 / FF26

- FF15 BB - 01 Flash Suppressor Set
- FF15 BB - 04 Rear Sight Set
- FF15 BB - 08 Piston Rod
- FF15 BB - 09 Assist Knob Set
- FF15 BB - 10 Inner Barrel
- FF15 BB - 11 Upper Receiver Set
- FF15 BB - 12 Charging Handle Set
- FF15 BB - 13 Hop-Up Set
- FF15 BB - 14 Port Cover Set
- FF15 BB - 15 Front Frame Lock Pin Set
- FF15 BB - 16 Bolt Catch Set
- FF15 BB - 17 Magazine Catch Set
- FF15 BB - 18 Selector Lever Set
- FF15 BB - 19 Stock Washer

- FF15 BB - 22 Lower Receiver Set
- FF15 BB - 23 Trigger Guard Set
- FF15 BB - 24 Selector Plate
- FF15 BB - 25 Rear Frame Lock Pin Set
- FF15 BB - 26 Grip
- FF15 BB - 27 Motor Set
- FF15 BB - 28 Grip Bottom Set
- FF15 BB - 30 Rear Wire Set
- FF15 BB - 31 Gear Box Set
- FF15 BB - 32 Blow Back Pneumatic Piston
- FF15 BB - 33 Charging Plate
- FF15 BB - 34 Selector Plate
- FF15 BB - 35 Charging Upper Cover
- FF15 BB - 36 Outer Barrel

For FF15-L / FF16

- FF15 BB - 05 Front Sight / Barrel Set
- FF15 BB - 21 Hi-Cap 450R Magazine

For FF15-L / FF26


- FF15 BB - 03 Rear Sight Base Set
- FF15 BB - 07 Barrel Base Set

For FF16 / FF26

- FF16 BB - 37 Enhanced Rod Set

For FF26

- FF26 BB - 41 Flash Suppressor
- FF26 BB - 42 Front Outer Barrel
- FF26 BB - 43 Handguard Set
- FF26 BB - 44 Retractable Stock Set
- FF26 BB - 45 300R Magazine



► You may purchase all of the groups' parts from G&G support Dep.

► E-Mail: support@guay2.com

TAIWAN

Changhua Tel : +886-4-798-9000 Fax : +886-4-798-9900
(Head Quarter) No.999, Zhonghua Rd. Shengang Township, Changhua County 50952, Taiwan (R.O.C.)
Taipei Tel : +886-2-2692-2000 Fax : +886-2-2692-4000
11F-3., No.27, Lane 169, Kangning St. Shijr City, Taipei County 22180, Taiwan (R.O.C.)

Sales Dept. sales@guay2.com, b2b@guay2.com
Technology Dept. support@guay2.com
PR Dept. pr@guay2.com

U.S.A.

Los Angeles Tel : +1-626-581-0101 Fax : +1-626-581-1011
1122 Colner Court City of Industry, CA91748 (U.S.A.)
sales101@guay2.com

