



GR4 G26 Instruction Manual

G&G ARMAMENT
AIRSOFT GUNS & ACCESSORIES

www.Guay2.com
Manufactured by G&G Armament
Printed in Taiwan



RETRACTABLE STOCK (GOS-V1)

CAUTION

Keep the selector on Safe mode until you are actually ready to shoot.



Press the stock release lever to unlock.




Adjust the position (6 position).



Extra Storage Space - Press the button then pull out.

SIGHT ADJUSTMENT



WINDAGE KNOB (left / right adjustment)
ELEVATION KNOB (up / down adjustment)



Rear Sight - Flip down or up



Front Sight - Flip down or up


MAINTENANCE



Remove the magazine.



Return the hop up dial to normal position and insert the cleaning rod from the lead edge of the inner barrel.



Be aware to have the rod facing down and reaching to the end, and remove clogged pellets.

TROUBLE SHOOTING



Adjust screw when the gear noise becomes shrilly.

The screw at bottom of the grip. Please use the screwdriver to adjust.



No operation

Check the wire set contact with motor.

OPTIONAL PARTS

G26 Laser & LED build-in Hand Guard Set




Red Laser - Pull and Turn the Knob. (Red / ON) (White / OFF)

Warning: Please follow the instruction to avoid the circuit short.



Led Light - Flip to turn on.

LASER BATTERY SETTING



Push the upper handguard forward and pull the knob toward flash hinder then pull out upward.



Pull out the cover and insert the CR123A battery.

LED LIGHT BATTERY SETTING



Unscrew both side and take off the front barrel.



Open the cover and insert the CR123A battery.

PARTS LIST

GR4 G26 - 01	Flash suppressor	GR4 G26 - 17	GMAG-V1 magazine
GR4 G26 - 02	Front barrel set	GR4 G26 - 18	Lower receiver set
GR4 G26 - 03	Lower handguard set	GR4 G26 - 19	Trigger guard set
GR4 G26 - 04	Upper handguard set	GR4 G26 - 20	Selector plate
GR4 G26 - 05	Hop-up set	GR4 G26 - 21	Rear frame lock pin set
GR4 G26 - 06	Slip ring set	GR4 G26 - 22	Grip set
GR4 G26 - 07	Inner barrel	GR4 G26 - 23	Motor set
GR4 G26 - 08	Upper receiver set	GR4 G26 - 24	Grip bottom set
GR4 G26 - 09	Charging handle set	GR4 G26 - 25	GOS-V1 stock set
GR4 G26 - 10	Port cover set	GR4 G26 - 26	Gear box set
GR4 G26 - 11	Front frame lock pin set	GR4 G26 - 27	Barrel base set
GR4 G26 - 12	Bolt catch set	GR4 G26 - 28	Blow back pneumatic piston
GR4 G26 - 13	Selector lever set	GR4 G26 - 29	Charging plate
GR4 G26 - 14	Magazine catch set	GR4 G26 - 30	Charging upper cover
GR4 G26 - 15	Stock washer	GR4 G26 - 31	Selector plate
GR4 G26 - 16	Enhanced rod set	GR4 G26 - 32	Rear Sight

MANUFACTURED BY G&G ARMAMENT

ADDRESS Changhua / No. 999, Zhonghua Rd., Shengang Township, Changhua County 50952, Taiwan
Taipei / 11F-3, NO.27, Lane 169, Kangning St, Shijr City, Taipei County 22180, TAIWAN

E-Mail Sales Department / sales@guay2.com
b2b@guay2.com


Technology support Department / support@guay2.com

WEBSITE www.guay2.com

TEL Changhua / 886-4-798-9000
Taipei / 886-2-2692-2000

FAX Changhua / 886-4-798-9900
Taipei / 886-2-2692-4000

Dealer



Please consult your dealer or G&G for overhaul maintenance and technical guidance.

► You may purchase all of the groups' parts from G&G support Dep.
► E-Mail: support@guay2.com