

## TAIWAN

ChangHua Tel: +886-4-798-9000 Fax: +886-4-798-9900 (Head Quarter) No.999, Zhonghua Rd. Shengang Township, Changhua County 50952, Taiwan (R.O.C.) **Taipei** Tel : +886-2-2692-2000 Fax : +886-2-2692-4000 11F-3., No.27, Lane 169, Kangning St. Shijr City, Taipei County 22180, Taiwan (R.O.C.)

Sales Dept. sales@guay2.com, b2b@guay2.com Technology Dept. support@guay2.com PR Dept. pr@guay2.com

## U.S.A.

Los Angeles Tel : +1-626-581-0101 Fax: +1-626-581-1011 1122 Coiner Court City of Industry, CA91748 (U.S.A.) sales101@guay2.com



WWW.GUAY2.COM **G&G** ARMAMENT AIRSOFT GUNS & ACCESSORIES

G2-201608-01 英















- All products employ a high precision 6.04mm barrel. Using 5.95mm BB pellets is highly recommended. Damage to the product due to faulty BB pellets voids the warranty. Use with caution.
- A The buyer and the user of this product shall adhere to all local laws regulating the usage and the ownership of airsoft guns.

- A This product is intended for users 18 years or older.
- A Read all instructions before using this product.
- Adult supervision required.
- Always wear safety goggles when using this product.
- Misuse or careless handling of this product may cause injury.
- ▲ May be hazardous up to 50 meters.



When you carry the air gun, attach the safety cap, set the selector lever to the safety position, and always put the air gun in a case or bag.



#### Orange tip disclaimer :

- All G&G Airsoft guns come with a permanent fixed orange tip required by law, which will grant Airsoft legal usage in the United States.
- ▲ If you alter, modify, abuse, or remove the orange tip, all warranty coverage will be void.

Never direct the muzzle towards a person, animal, or in any direction that may cause harm or damage to a third party.



Safety procedures: 1. Attach the safety cap to the muzzle. 2. Set the selector lever to the safety position. 3. Remove the magazine.

You may be liable for damaging

public, personal property, or for

injuring a person or an animal.

Always observe good manners

and enjoy fun sport shooting.





Select a safe place for operating the air gun and avoid places where people and cars are around.

When shooting the air guns for target practice or in a game situation, you and all participants must wear safety goggles or other eye protective gear. Please pay attention to ricochets and third parties around you.





Always attach the safety cap to the muzzle, remove the battery and store the air gun in a case or bag and at a place that is out of reach of children.

Looking into the muzzle is extremely dangerous, regardless of having BB's loaded or not. If you get hit in the eye by a BB pellet, worst case scenario, you may lose your eye sight.

There may be cases where some BB's remain in the gun after the magazine has been removed. After removal of the magazine, direct the muzzle towards a safe direction and pull the trigger to confirm that there are no BB's remaining in the gun, then attach the safety cap.



Warning

For more product information please visit our website www.guay2.com





Make sure to put the barrel and safety cap onto the muzzle except when shooting, to prevent any accidents, discharge of BB's, and also for dust protection purposes. Never pull the trigger while the barrel and safety cap are attached.



Activating the trigger carelessly is extremely dangerous. Never put your finger on the trigger unless the safety cap is removed and you are ready to shoot a target.



Disassembling or modifying the gun may adversely affect the performance and make it dangerous. It would also void all warranty.













# RK SERIES LINE

)

**★ RK104 EVO** (P6 \ 15 \ 17 \ 21~23 \ 25~26 \ 31~32)

**RK104 EVO CRANE** (P6 \ 15~16 \ 21~23 \ 25~26 \ 33~34)

**RK103 EVO** (P6 \ 15 \ 17 \ 21~23 \ 25~26 \ 31~32)

**RK103 EVO CRANE** (P6 \ 15~16 \ 21~23 \ 25~26 \ 33~34)











#### RK47 WOOD







# **RK103 / RK104 / RK103 EVO / RK104 EVO**









### **III** GKM / GIMS

















#### GK74 CARBINE

For more product information









Selector Lever

Handguard

Magazine

Magazine

Catch

#### **RK BETA / GKS74U**



# COMPONENTS 12

#### **GK99**

CORE OF CREW

and the second

For more product information please visit our website www.guay2.com







In order to simulate the bolt action of a real firearm, G&G is proud to present its new Pneumatic Blow Back system to its line of airsoft guns.

Conventional airsoft blow back utilizes tow hook springs that connect to the piston head and bolt plate to simulate bolt action, which often lead to excess wear and tear and poor reliability in the gear box. To alleviate the problem of conventional systems, G&G has independently developed the Pneumatic Blow Back system for a better solution on simulating bolt actions.

This new technology utilizes compressed air to move the bolt, which enables the action without adding extra stress to the gear box.

This class leading system represents a significant milestone in the airsoft industry.

BLOW BACK SYSTEM

13









## PATENTS

#### **EUROPEAN UNION**

Patent No. 460191 814454

Patent No. 200620122468.9

#### DENMARK

Patent No. BA2007 0069

Patent No. 614422.4

#### The Director of the United State Patent and Trademark Office

States

Americ

#### United States Patent

application was filed prove to June



# SELECTOR & SAFETY SETTING









FULL AUTO

AUTOMATIC FIRING

#### **A** CAUTION

SEMI AUTO SINGLE SHOT

Never operate the selector switch while pulling the trigger. Otherwise, malfunctions may occur.

> Pulling the trigger with the Selector being set at safe mode may damage the air gun.

### **A** CAUTION

Direct the muzzle towards a safe direction and set the selector to the safety position. The magazine should be removed before changing the battery.

#### For GKM / GIMS / GK74 / GK74N





Remove the handguard battery.

Push the button and pull forward to unlock the handguard battery.

### For RK103 EVO CRANE / RK104 EVO CRANE



1. Pull and hold the stock release lever mount. 2. Pull out the stock.



1. Turn and take off the battery cover. 2. Insert the battery into the stock.

#### SAFETY ON THE TRIGGER CANNOT BE PULLED



When the gun is in storage or not being fired, always set the selector to the Safe position and attach the protective cap on the muzzle.



The gun will fire continuously while the trigger remains pulled.



The gun will fire one shot each time when the trigger is pulled.

# BATTERY SETTING 16



#### [ Power ] Blue Light (ON)

[Error Status] Red Light (Flashing) / [Normal] Red Light (OFF) [Fully Charged ] Green Light (ON) / [Normal ] Green Light (OFF)

When the green light flashing more frequently shows the charging speed is faster. When the battery is nearly full, the green light will be on consistently.

**LED** Indication

#### **A** CAUTION

Make sure the longitudinal slits always present on pin connector. If the pin connector has been deformed, it may disable the firing function!





1. Connect the battery plug into the connector until you hear a 'click'. 2. Reinstall the stock.









A CAUTION Direct the muzzle towards a safe direction and set the selector to the safety position. The magazine should be removed before changing the battery.

#### For RK47 / RK103 / RK104 / RK103 EVO / RK104 EVO



Unscrew the fixing screws and remove the plate



Connect the battery until you hear a 'click'.



Insert the battery and reinstall the plate.



#### For GK99





#### For RK Beta



Push the stock plate and remove.



Connect the battery plug with the connector until you hear a 'click'.



Reinstall the stock plate.

















CAUTION Direct the muzzle towards a safe direction and set the selector to the safety position. The magazine should be removed before changing the battery.

#### For GKS74U / GK74 Carbine / GKMS Carbine



Push the cover release button and remove the dust cover.



Connect the battery until it clicks into place.



Put back the dust cover.







Push the stock lock lever to unlock the folding stock.



Push the stock lock button to unlock.

#### For GKMS / GKMS Carbine



Push the stock lock button to unlock.



Unfold the underfolding stock and make sure it is securely locked in place.



Fold down the end of stock for better shouldering.



Unfold the stock and make sure it is securely locked in place.



Fold the stock to the side and make sure it is securely locked in place.







Squeeze both arms of the stock to unlock.



Unfold the stock and make sure it is securely locked in place.









**CAUTION** Confirm that the safety lever is set to the Safety position and do not place your finger on the trigger.

#### For All RK Series

### **A** CAUTION

Always use the G&G BB pellet or diameter 5.94 ~ 5.96 mm BBs for this air gun. G&G shall not be held responsible for any damage or accidents arising from the use of pellets supplied by other manufacturers.





Open the cover of the magazine and load G&G 5.95mm BB pellets into the magazine.

#### Front Sight Adjustment or All RK Series



Insert the front sight adjustment tool into the front sight block.



Clockwise : Lower the front sight. Counterclockwise : Raise the front sight.

#### Front Sight Adjustment For GK99



Use the screwdriver to adjust the front sight

Flip-Up night front sight.

#### For All RK Series



Turn the winding wheel on the bottom of the magazine to tighten the spring. This will allow the BBs to feed through the top of the magazine.



Insert the magazine as shown in the picture 4.



Make sure the magazine is securely inserted into the receiver until it clicks.



windage.

# SIGHT ADJUSTMENT

### **CAUTION** Ensure not to lose the adjustment tool.





Press the button and slide forward or backward for adjustment.

#### **Rear Sight Adjustment** For GK99





Full Auto shooting.



Precision shooting.









#### **CAUTION** Do not to catch your fingers in the dummy bolt.

**\* NOTE** Adjust only when the gear noise becomes shrill.

#### For All RK Series



Pull the handle in the direction shown to open the bolt.



Slide the hop-up adjustment piece forward or backward to adjust the Hop-up effect.





Unscrew the fixing screw on the bottom of the grip and remove the grip.

#### For GKS74U / GK74 Carbine / GKMS Carbine



1. Push the cover release button. 2. Remove or lift up the dust cover.

Unscrew the screws of the Hop-up unit.

The front kit can now be disassembled.



Push the rear-end of the spring guide to remove the bolt set.

#### For GKM / GKMS / GIMS / GK74 / GK74N



the handguard battery.

**CAUTION** Never hold the gun sideways as the BB pellets will curve right or left. Too much HOP-UP. (Return the lever toward NORMAL) 0 Best direction. Not enough HOP-UP.(Move the lever toward HOP) Or too much HOP-UP.(Return the lever toward NORMAL)



# FRONT KIT DISASSEMBLY





Use 2mm hexagon key to unscrew the barrel bracket set screws.



Unscrew the screw and the front kit can now be disassembled.



# **G&G**ARMAMENT



Never use CRC-556, WD40 or other corrosive lubricant.



#### 1. After Operation

Remove the magazine, direct the muzzle into a safe direction, then fire the gun in semi-auto mode for a few shots. Set the selector to the safe position. Always disconnect the battery and attach the protective cap whenever you are not operating the air gun.

#### 2. Cautions on Motor and Battery

Charge the battery if the firing cycle becomes slow. Stop the usage of the air gun for 5 to 10 minutes after firing around 500 rounds in order to ensure the long life of the motor and battery.

#### 3. Clogged Pellets

If pellets are clogged, remove and apply a few drops of G&G's silicone oil into the chamber from the magazine entrance. Apply the silicone for 0.4 to 1 sec to obtain smooth continuous firing.

# A CAUTION Make sure no dirt gets into the chamber to avoid clogging of pellets. The hop up operation may be unstable for the first 200 to 300 rounds after using silicone oil, this is the normal operation of the gun.





1. Place a few drops of silicone oil or teflon oil into the pellet entrance. After inserting BB pellets into the magazine, fire the gun around 200-300 rounds.

2. To complete the cleaning, use the cleaning rod (with cotton) to remove excess oil.

#### **REMOVING CLOGGED PELLETS**



**CAUTION** Do not jam the cleaning rod into the barrel by force. Should the BB's remain inside the barrel after following the instruction above, point the gun to a safe direction and discharge any loosened BB's in semi-automatic mode.

#### **Troubleshooting**

SYMPTOM	POTENTIAL	CORRECTIVE	
	Selector lever is set to safety.	Set the selector lever to Semi or Full Auto.	
	Battery is not charged.	Charge the battery.	
No operation at all	Battery connector is disconnected.	Connect the connector.	
No operation at all	The Gand of battery connector is reversed.	Switch the batteries to the correct position.	
	Expired motor life (50,000 to 60,000 rounds) or poor electrical connection.	Replace the dead motor (can be purchased from local dealer or directly from G&G). Check and repair the contacts.	
Although motor is revolving, no	Pellets are clogged inside the magazine.	Insert the charging rod into the magazine and move up and down a few times to remove clogged pellets.	
pellet can be fired	Pellets are clogged in the chamber.	Remove clogged pellets using the cleaning rod.	
	Faulty gear.	Purchase the replacement gear from your dealer or G&G and repair.	
Impossible full-auto	Insufficient battery power.	Charge the battery.	
	Faulty pellet feed of magazine.	Repair clogging of the magazine.	
operation(automatic firing)	Poor electrical connection.	Consult your dealer or G&G for overhaul maintenance or repair.	
	Damaged or worn chamber set.	Replace the replacement parts (purchase from your dealer or G&G)	
	Damaged or worn piston set (O-ring,piston spring)		
Chapting distance becomes	Something is jammed in the inner barrel	Use the cleaning rod and clean the inner barrel.	
Shooting distance becomes shorter	Faulty BB pellets (too small or heavy)	Use the genuine G&G Pellets.	
Shorter	Shortage of silicone oil	Place a few drops of silicone oil onto the upper chamber.	
	Gear problem caused by too many blank firing		
Level an exetine maine	Worn or damaged gear		
Loud operating noise	Gear problem caused by too many blank firing	Consult your dealer or G&G for overhaul maintenance, part replacement (gear,etc.) or repair.	
	Damaged or worn chamber set.	(gear,etc.) of repair.	
Pellets being fallen out from	No hop setting.	Turn the hop adjustment lever toward Hop.	
barrel end	Faulty BB Pellets (too small or heavy)	Use the G&G Pellets.	
If gun gets wet	Stop operation immediately, disconnect the battery, w completely dry, carry out trial firing. If the unit is not o	vipe off water from inside the main body and the battery. After the gun is perational, please contact your local dealer for repair.	

#### Disclaimer

- Accessories pictured are not always included with product.
- Adult supervision required for users under 18 years of age.
- The purchaser and user should conform to all laws governing the ownership of airsoft guns.

- manufacturers.
- pictured.

TROUBLESHOOTING

All products in this manual are imitation firearms and are not intended nor represented to be comparable in design, appearance, or function to any actural firearm offered by other

Product names are trademarks of G&G, which has no affiliation to, and is not associated, or sponsored by any manufacturer of actual or imitation firearms. Products may vary form those













RK47-001
RK47-002
RK47-003
RK47-004
RK47-005
RK47-006
RK47-007
RK47-008
RK47-009
RK47-010
RK47-011
RK47-012
RK47-013
RK47-014
RK47-015
RK47-016
RK47-017
RK47-018
RK47-019
RK47-020
RK47-021
RK47-022
TACH OLL

for RK47

Receiver Cover Set Rear Sight Set Bolt Set Gas Block Set Rail Mount Set **Receiver Set** Barrel Base Set Gas Cylinder Set Outer Barrel Set Front Sight Set Butt Stock Set Selector Lever Set Gear Box Set Hop Up Set Inner Barrel Clean Rod Grip Set Motor Base Set Motor Set Handguard Set Trigger Guard Set Magazine

PARTS LIST













PART	S LIST >⊐□
for RK103 /	RK104
RK103-001	Receiver Cover Set
RK103-002	Rear Sight Set
RK103-003	Bolt Set
RK103-006	Receiver Set
RK103-007	Barrel Base Set
RK103-008	Gas Cylinder Set
RK103-011	Butt Stock Set
RK103-012	Selector Lever Set
RK103-013	Gear Box Set
RK103-014	Hop Up Set
RK103-017	Grip Set
RK103-018	Motor Base Set
RK103-019	Motor Set
RK103-020	Handguard Set
RK103-021	Trigger Guard Set
RK103-022	Magazine

for RK103
RK103-004
RK103-005
RK103-009
RK103-010
RK103-015

Gas Block Set Flash Suppressor Set Outer Barrel Set Front Sight Set Inner Barrel RK103-016 Clean Rod

#### for RK104

RK104-005
RK104-009
RK 104-009
RK104-010
RK104-015
RK104-016

Flash Suppressor Set Outer Barrel Set Front Sight Set Inner Barrel Clean Rod















# PARTS LIST for RK103 EVO / RK104 EVO

RK103E-003 Bolt Set RK103E-006 Receiver Set RK103E-012 RK103E-014 Hop Up Set RK103E-017 Grip Set RK103E-019 Motor Set RK103E-022 Magazine

RK103E-001 Receiver Cover Set RK103E-002 Rear Sight Set RK103E-007 Barrel Base Set RK103E-008 Gas Cylinder Set RK103E-011 Butt Stock Set Selector Lever Set RK103E-013 Gear Box Set RK103E-018 Motor Base Set RK103E-020 Handguard Set RK103E-021 Trigger Guard Set

#### for RK103 EVO

RK103E-004
RK103E-005
RK103E-009
RK103E-010
RK103E-015
RK103E-016

Gas Block Set Flash Suppressor Set Outer Barrel Set Front Sight Set Inner Barrel Clean Rod

#### for RK104 EVO

RK104E-005 Flash Suppressor Set RK104E-009 Outer Barrel Set RK104E-010 Front Sight Set RK104E-015 Inner Barre RK104E-016 Clean Rod









for RK103 EVO CRANE / RK104 EVO CRANE





#### for RK103 EVO CRANE / RK104 EVO CRANE

PARTS LIST

RK103EC-03 Bolt Set RK103EC-06 RK103EC-08 RK103EC-11 RK103EC-13 RK103EC-14 Hop Up Set RK103EC-17 Grip Set RK103EC-19 Motor Set RK103EC-22 Magazine RK103EC-23 Cord Set

RK103EC-01 Receiver Cover Set RK103EC-02 Rear Sight Set Receiver Set RK103EC-07 Barrel Base Set Gas Cylinder Set Butt Stock Set RK103EC-12 Selector Lever Set Gear Box Set RK103EC-18 Motor Base Set RK103EC-20 Handguard Set RK103EC-21 Trigger Guard Set

#### for RK103 EVO CRANE

RK103EC-15 Inner Barre RK103EC-16 Clean Rod

RK103EC-04 Gas Block Set RK103EC-05 Flash Suppressor Set RK103EC-09 Outer Barrel Set RK103EC-10 Front Sight Set

#### for RK104 EVO CRANE

RK104EC-05
RK104EC-09
RK104EC-10
RK104EC-15
RK104EC-16

5 Flash Suppressor Set Outer Barrel Set Front Sight Set nner Barre Clean Rod















#### for RK BETA

RKBETA-001
RKBETA-002
RKBETA-003
RKBETA-004
RKBETA-005
RKBETA-006
RKBETA-007
RKBETA-008
RKBETA-009
RKBETA-010
RKBETA-011
RKBETA-012
RKBETA-013
RKBETA-014
RKBETA-015
RKBETA-016
RKBETA-017
RKBETA-018
RKBETA-019

**Receiver Cover Set** Bolt Set Flash Suppressor Magazine **Receiver Set** Barrel Base Set Gas Cylinder Set Front Sight Set Butt Stock Set Selector Lever Set Gear Box Set Hop Up Set Outer Barrel Inner Barre Grip Set Motor Base Set Motor Set Rail Handgurad Set **Trigger Guard Set** 









for GK99 BlowBack Ver.



2 3 D (0)GK GK For more product information. Please visit our website WWW.GUAY2.COM



#### for GK99 BlowBack Ver.

PARTS LIST

GK99BB-001	Receiver Cover Set
GK99BB-002	Bolt Lever Set
GK99BB-003	Bolt Guide Set
GK99BB-004	Gas Tube
GK99BB-005	Receiver Set
GK99BB-006	Handguard Set
GK99BB-007	Gas Block Set
GK99BB-008	Front Sight Set
GK99BB-009	Flash Suppressor
GK99BB-010	Folding Stock Set
GK99BB-011	Grip
GK99BB-012	
010000012	Selector Lever Set
GK99BB-012	Gear Box Set
GK99BB-013	Gear Box Set
GK99BB-013 GK99BB-014	Gear Box Set Hop Up Set
GK99BB-013 GK99BB-014 GK99BB-015	Gear Box Set Hop Up Set Outer Barrel Set
GK99BB-013 GK99BB-014 GK99BB-015 GK99BB-016	Gear Box Set Hop Up Set Outer Barrel Set Inner Barrel
GK99BB-013 GK99BB-014 GK99BB-015 GK99BB-016 GK99BB-017	Gear Box Set Hop Up Set Outer Barrel Set Inner Barrel Motor Base Set





PART	
<b>FANI</b> ,	
for GK74 / GK	74N / GKS74U
GK74 - 012	Selector Lever Set
GK74 - 014	Selector Lever Set Hop Up Set
GK74 - 017	Grip Set
GK74 - 018	Motor Base Set
GK74 - 010	Motor Set
GK74 - 021	Trigger Guard Set
GK74 - 022	Magazine
for GK74 / GK	74N
GK74 - 001	Receiver Cover Set
GK74 - 002	Rear Sight Set
GK74 - 003	Bolt Set
GK74 - 004	Gas Block Set
GK74 - 005	Flash Suppressor Set
GK74 - 007	Barrel Base Set
GK74 - 008	Gas Cylinder Set
GK74 - 009	Outer Barrel Set
GK74 - 010	Front Sight Set
GK74 - 013	Gear Box Set
GK74 - 015	Inner Barrel
GK74 - 016	Clean Rod
GK74 - 020	Handguard Battery Set
GK74 - 023	Cord Set
GK74 - 024	Battery Charger Set
for GK74 / GK	
GK74 - 006	Receiver Set
GK74 - 011	Folding Stock Set
for GKS74U	
	Receiver Cover Set
GKS74U-003	Bolt Set
GKS74U-005	Flash Suppressor Set
GKS74U-008	Gas Cylinder Set
GKS74U-009	Outer Barrel Set
GKS74U-010	Front Sight Set
GKS74U-015	Inner Barrel
GKS740-020	Handguard Set
for GK74N	
GK74N-006	Receiver Set

GK74N-011 Butt Stock Set



PART	
for GIMS / G	KM
GIMS - 001	Receiver Cover Set
GIMS - 002	Rear Sight Set
GIMS - 003	Bolt Set
GIMS - 004	Gas Block Set
GIMS - 005	Flash Suppressor Set
GIMS - 007	Barrel Base Set
GIMS - 008	Gas Cylinder Set
GIMS - 009	Outer Barrel Set
GIMS - 010	Front Sight Set
GIMS - 012	Selector Lever Set
GIMS - 013	Gear Box Set
GIMS - 014	Hop Up Set
GIMS - 015	Inner Barrel
GIMS - 016	Clean Rod
GIMS - 017	Grip Set
GIMS - 018	Motor Base Set
GIMS - 019	Motor Set
GIMS - 021	Trigger Guard Set
GIMS - 022	Magazine
GIMS - 023	Cord Set
GIMS - 024	Battery Charger

for GIMS
GIMS - 006
GIMS - 011
GIMS - 020

Receiver SetFolding Stock SetHandguard Battery Set

for GKM
GKM - 006
GKM - 011
GKM - 020

Receiver Set Butt Stock Set Handguard Battery Set









# You may buy all groups' parts from G&G Support Dept. Email: support@guay2.com GKMS MS - 022 θ \$ 3 **₩**



DADTO	
PARTS	
fee CKNAC	
for GKMS	
GKMS - 001	Receiver Cover Set
GKMS - 002	Rear Sight Set
GKMS - 003	Bolt Set
GKMS - 004	Gas Block Set
GKMS - 005	Flash Suppressor Set
GKMS - 006	Receiver Set
GKMS - 007	Barrel Base Set
GKMS - 008	Gas Cylinder Set
GKMS - 009	Outer Barrel Set
GKMS - 010	Front Sight Set
GKMS - 011	Folding Stock Set
GKMS - 012	Selector Lever Set
GKMS - 013	Gear Box Set
GKMS - 014	Hop Up Set
GKMS - 015	Inner Barrel
GKMS - 016	Clean Rod
GKMS - 017	Grip Set
GKMS - 018	Motor Base Set
GKMS - 019	Motor Set
GKMS - 020	Handguard Battery Set
GKMS - 021	Trigger Guard Set
GKMS - 022	Magazine
GKMS - 023	Cord Set
GKMS - 024	Battery Charger
	, <u> </u>













# for GKMS Carbine / GK74 Carbine

	bille
GKMS C - 01	Receiver Cover Set
GKMS C - 03	Bolt Set
GKMS C - 05	Flash Suppressor Set
GKMS C - 08	Gas Cylinder Set
GKMS C - 09	Outer Barrel Set
GKMS C - 10	Front Sight Set
GKMS C - 12	Selector Lever Set
GKMS C - 13	Gear Box Set
GKMS C - 14	Hop Up Set
GKMS C - 15	Inner Barrel
GKMS C - 17	Grip Set
GKMS C - 18	Motor Base Set
GKMS C - 19	Motor Set
GKMS C - 20	Handguard Set
GKMS C - 21	Trigger Guard Set

PARTS LIST YE

#### for GKMS Carbine

GKMS	С	-	06
GKMS	С	-	11
GKMS	С	-	22

Receiver Set Folding Stock Set Magazine

#### for GK74 Carbine

GK74 C - 22 Magazine

GK74 C - 06 Receiver Set GK74 C - 11 Folding Stock Set



## GK74M GKG74IM CLASSIC EDITION







#### CAUTION Direct the muzzle towards a safe direction and set the selector to the safety position. The magazine should be removed before changing the battery.



1. Push the button and pull forward to unlock the handguard battery. 2.Remove the handguard battery.

#### Folding Stock (GKS74 / GKSG74 )





1. Push the stock lock button to unlock. 2. Turn to fold the stock.



Battery Setting (GKS74 / GK74M)

Power : Blue Light (ON) Error Status : Red Light (Flashing) Normal : Red Light (OFF) Fully Charged : Green Light (ON) Normal : Green Light (OFF)

When the green light flashing more frequently shows the charging speed is faster. When the battery is nearly LED Indication full, the green light will be on consistenly.



# BATTERY & STOCK SHE



1. Push the cover release button to remove the bolt. 2.Connect the battery unit it clicks, then put back the cover.



1. Push the stock lock button to unlock. 2. Turn to fold the stock.





# GKS741/GKSG741 GK741MI/GKG741MI Manual











#### for GKS74 / GKSG74 / GK74M / GKG74M

001 Bolt Cover 002 Rear Sight Set 003 Bolt Set 004 Gas Block Set 005 Flash Suppressor Set 006 Receiver Set 007 Barrel Base Set 008 Gas Cylinder Set 009 Outer Barrel Set 010 Front Sight Set 011 Folding Stock Set 012 Selector Lever Set 013 Gear Box Set 014 Hop Up Set 015 Inner Barrel 016 Dummy Rod 017 Grip Set 018 Motor Mount Set 019 Motor Set 020 Handguard Battery\_GKS74/GK74M 021 Trigger Guard Set 022 Magazine 023 Charger Adapter GKS74/GK74M 024 Battery Charger GKS74/GK74M 025 Lower Handguard Retainer 026 Handguard GKSG74/GKG74M 027 Wire Set\_GKSG74/GKG74M